

Quick Start Guide

THIS QUICK START GUIDE IS DESIGNED AS A QUICK REFERENCE GUIDE, IT IS NOT A SUBSTITUTE FOR READING OWNERS MANUAL. YOU MUST READ OWNERS MANUAL BEFORE USING WRAPPER.

1. Move wrapper to area where you want to wrap, then disengage both self-propelled drive wheels. Pg. 13
2. Start and run gas engine then lower tailgate, "tailgate can be left in horizontal position to start" lower tailgate as first bales come to the end of tailgate.
3. Adjust the two bale guides for the size of bale being wrapped.
4. Adjust the two electronic eyes on each side of machine for the size of bale being wrapped, "Eyes need to be adjusted to keep web chain full while giving yourself just enough room to load next bale" . See page 21 for further details on positioning the electric eyes.
5. Load plastic rolls of film, see pg. Pg.19
6. Main switch on control panel needs to be on "System Manual" to start wrapping manually.
7. Set first bales on wrapper and start wrapping in manual mode by activating "Hoop Forward" and "Web Forward switches. Pg.20
8. Set amount of layers of plastic. Pg.21
9. When first wrapped bales are on the ground, wrapper can be switched to wrap in automatic mode by (1) putting main switch to "Remote On, System Automatic" (2) pushing green button on handheld remote control (3) pushing "Wrap Start" on handheld remote control. **Wrapper will now automatically start wrapping as soon as a bale is set on unit.**
- 10.If needed apply brake pressure to pack bales tighter .
- 11.If needed tailgate can be slightly lifted when wrapping to reduce ground drag.